


INSTALLATION OPERATIONS

1. REFER TO OWNERS MANUAL FOR CABINET INSTALLATION AND ANCHORING.
2. DETERMINE THE LOCATION OF THE SHELF or SHELVES. INSTALL THE LEFT HAND AND RIGHT HAND SHELF SUPPORTS BY INSERTING THE REAR TANGS INTO THE RECTANGULAR SLOTS OF THE REAR FRAME MEMBER AND ATTACH FRONT OF SUPPORTS TO THE FRONT FRAME MEMBER WITH TAPPING SCREWS AS SHOWN. MAKE SURE THE SUPPORTS ARE LEVEL AND IN-LINE WITH EACH OTHER SIDE TO SIDE.
3. PLACE THE SHELF or SHELVES ON THE SUPPORTS

(2) 1/4-20 x 1/2"
T30 TORX PAN HEAD
TAPPING SCREW

SUPPLIED FASTENERS



LYON
P.O. Box 671
AURORA, IL 60507-0671
PHONE: 630-892-8841
FAX: 800-867-4681

NOTICE: THIS IS A CONFIDENTIAL DISCLOSED LOANED BY LYON WORKSPACE FOR REFERENCE PURPOSES ONLY

DATE	DRAWN BY	CHECKED BY
01-19-12	JR	DWV

INSTALLATION
CABINET SHELF
MDC

SHEET	DRAWING NUMBER	REV
-	5163-DA	5