



(2) 1/4-20 x 1/2"
T30 TORX PAN HEAD
TAPPING SCREW

SUPPLIED FASTENERS

INSTALLATION OPERATIONS

1. REFER TO OWNERS MANUAL FOR CABINET INSTALLATION AND ANCHORING.
2. DETERMINE THE LOCATION OF THE SHELF or SHELVES. INSTALL THE LEFT HAND AND RIGHT HAND SHELF SUPPORTS BY INSERTING THE REAR TANGS INTO THE RECTANGULAR SLOTS OF THE REAR FRAME MEMBER AND ATTACH FRONT OF SUPPORTS TO THE FRONT FRAME MEMBER WITH TAPPING SCREWS AS SHOWN. MAKE SURE THE SUPPORTS ARE LEVEL AND IN-LINE WITH EACH OTHER SIDE TO SIDE.
3. PLACE THE SHELF or SHELVES ON THE SUPPORTS

△	REVISED SHELF	0565	06-25-08	RE
△	REVISED SHELF	0410	06-20-00	RE
△	REVISED FOR NEW MDC CABINET	0376	10-18-99	RE
△	REVISED		08-16-95	
△	RELEASED		12-03-87	
SYM	REVISION	ECN	DATE	BY

NOTES:		
1) ALL DIMENSIONS ARE INCHES		
MATERIAL ---		
RAW P/N 101273	WEIGHT(LB) ---	FINISH: ---
DATE 12-03-87	REDRAWN BY RE	CHECKED BY DV
LYON		
LYON METAL PRODUCTS PO BOX 671 AURORA, IL 60507 (800) 323-0082 FAX: (800) 367-6681		
MDCII	DESCRIPTION INSTALLATION - CABINET SHELF	
SHEET	DWG NUMBER 5163-DA	REV 5

NOTICE: THIS IS A CONFIDENTIAL DISCLOSURE. LOANED BY LYON METAL PRODUCTS FOR REFERENCE PURPOSES ONLY