



INSTALLATION INSTRUCTIONS

- 1) DRAWERS-IN-SHELVING EXTERNAL LOCKBARS CAN ONLY BE MOUNTED TO THE T-POSTS AFTER ALL SHELVING, FRAMES AND DRAWERS HAVE BEEN INSTALLED.
- 2) LOCATE EXTERNAL LOCKBAR AS SHOWN ON THE LEFT SIDE OF THE DRAWERS. WITH A #27 (Ø 0.144) DRILL BIT, USING THE HOLES ON THE HINGE OF THE EXTERNAL LOCKBAR AS A GUIDE, DRILL HOLES THROUGH THE T-POST.
- 3) SECURE THE EXTERNAL LOCKBAR TO THE T-POST USING THE SUPPLIED THREAD CUTTING SCREWS.

NOTES: THIS IS A CONFIDENTIAL DISCLOSURE (OWNED BY STAMBE SYSTEMS FOR REFERRED PURPOSES ONLY)	REL FOR PROD		0584	07-30-09	RE
	SYN		REVISION	ECN	DATE
	DATE	DRAWN BY	CHECKED BY		
	07-30-09	RE	DV		
LYON		LYON WORKSPACE PRODUCTS PO BOX 671 ALZORA, IL 60507 (800) 323-0082 FAX: (800) 367-6681			
		DESCRIPTION			
MDCII	DIS ELB INSTALL				
SHEET	DWG NUMBER		REV		
	SS1444		1		