



SINGLE ROW, SLOPING TOP LOCKERS

GENERAL INSTRUCTIONS:

- 1) PLEASE READ COMPLETE ASSEMBLY INSTRUCTIONS BEFORE ATTEMPTING TO ASSEMBLE LOCKERS. FOR ACCESSORIES, SEE SHEET 3.
- 2) CHECK THE MATERIAL TO BE SURE THAT IT IS CORRECT FOR THE JOB AND THAT THERE IS NO DAMAGE.
- 3) BE CAREFUL TO USE THE CORRECT HARDWARE SPECIFIED. USE BOLT NO. 1 ALL AROUND WITH BOLT HEADS OUT EXCEPT AS NOTED.
- 4) LOCKERS SHOULD BE ASSEMBLED IN GROUPS AS INDICATED ON THE ORDER OR DRAWINGS.
- 5) THE ESSENTIAL TOOLS REQUIRED FOR ASSEMBLING LOCKERS ARE: A REGULAR SCREWDRIVER, TWO DRIFT PINS (OR TWO NAIL PUNCHES) FOR HOLE ALIGNMENT, AND A 3/8" SOCKET WRENCH.
- 6) LOCKERS SHOULD BE ASSEMBLED ON A FLAT LEVEL SURFACE AND ANCHORED PER SHEETS 5 & 6.




HARDWARE:



NOTE: FOR HEAVY DUTY LOCKERS, USE NO. 2 BOLT ONLY.


OPERATION #1

BOLT A SLOPING TOP, BOTTOM, AND HOOK TO A BACK. THE TOP AND BOTTOM MUST HAVE FLANGES DOWN. BACK TO HAVE FLANGES UP & FLANGE BEVEL AT TOP. HOOK TO MOUNT BELOW SHELF LOCATION.



OPERATION #2

BOLT A LEFT HAND SLOPING SIDE, WITH FLANGE IN, TO OPERATION #1 ASSEMBLY (OMIT 2 BOLTS NEAR BOTTOM REAR FOR LEGS, IF REQUIRED). BOLT A SHELF WITH FLANGES DOWN & 45° FLANGE IN FRONT TO THE SIDE AT DESIRED LOCATION (E.G. 9", 12", ETC.).




SECTION A - A

NOTE: SINGLE ROW SLOPING SIDES ARE MADE EITHER RIGHT OR LEFT HAND. THEY ARE NOT REVERSIBLE.

OPERATION #3

BOLT SIDE HOOKS IN PLACE BELOW SHELF (USE NO. 2 BOLTS FOR HOOKS TO BE BACK TO BACK WITH THE SIDE BETWEEN EACH COMPONENT). USE NO. 1 BOLTS ON TOPS, BOTTOMS, SHELVES AND BACKS. PLACE EACH OF THE ABOVE COMPONENTS SIDE TO SIDE WITH A LOCKER SIDE SHEET BETWEEN AND BOLT IN PLACE. ATTACH COAT RODS IF REQUIRED (SEE ACCESSORIES PAGE). REPEAT THIS OPERATION UNTIL REQUIRED LOCKER UNITS ARE ASSEMBLED.



SECTION B - B

E-061201-1

**MISSING PARTS OR IN NEED
OF
ASSEMBLY ASSISTANCE?**

Contact us direct for fast friendly service (800) 433-8488

Int'l calls (630) 892-8941 | WEB: WWW.LYONWORKSPACE.COM | Fax (800) 367-6681

ASSEMBLY INSTRUCTIONS
FOR LYON SINGLE ROW
SLOPING TOP STEEL
LOCKERS


LYON LYON WORKSPACE PRODUCTS
P.O. BOX 671
AURORA, IL 60507

6226-CA

SHEET 1 OF 6

OPERATION #4


ADD A RIGHT HAND SLOPING SIDE, WITH FLANGE IN, TO OPERATION #3 ASSEMBLY. INSERT REAR LEGS, IF REQUIRED, IN EACH END LOCKER AT 36" MAXIMUM SPACING, AND BOLT IN LEAVING BOLTS LOOSE. ADD A DOUBLE PRONG HOOK UNDER EACH SHELF AND ADD A SINGLE PRONG HOOK TO THE LAST SIDE.



OPERATION #5


1) ATTACH DOOR AND FRAME ASSEMBLIES TO LOCKERS BEING SURE THE SIDE IS NEVER BETWEEN FRAMES (SEE SECTION A-A). LEAVE TOP, CENTER AND BOTTOM BOLTS OUT ON EXTREME ENDS OF GROUPS FOR ATTACHING FILLERS OR ADDITIONAL GROUPS. USE DRIFT PINS (OR NAIL PUNCHES) TO ALIGN TOP & BOTTOM HOLES OF FRAME.

2) ATTACH SLOPING TOP TO DOOR AND FRAME ASSEMBLY USING NO. 3 SCREW.



OPERATION #6

STAND GROUPS IN PLACE. LEVEL THEM AND ADJUST REAR LEGS TO TOUCH FLOOR AND TIGHTEN BOLTS. BOLT GROUPS TOGETHER USING BOLTS OMITTED IN OPERATION #5. ATTACH LOCK HOLE FILLERS AS REQUIRED.



ADJACENT DOOR FRAMES OF GROUPS

E-010120-2

MISSING PARTS OR IN NEED OF ASSEMBLY ASSISTANCE?

Contact us direct for fast friendly service (800) 433-8488

Int'l calls (630) 892-8941 | WEB: WWW.LYONWORKSPACE.COM | Fax (800) 367-6681

ASSEMBLY INSTRUCTIONS
FOR LYON SINGLE ROW
SLOPING TOP STEEL
LOCKERS


LYON  LYON WORKSPACE PRODUCTS
P.O. BOX 671
AURORA, IL 60507

6226-CA

SHEET 2 OF 6

ACCESSORIES


COAT ROD



COAT ROD CLIP




NO. 1 SLOTLESS
BOLT & NUT
#10 X 3/8"
ROUND HEAD



NO. 2 SLOTLESS
BOLT & NUT
#10 X 1/2"
ROUND HEAD

COAT RODS ARE ATTACHED TO THE LOCKER
SIDES WITH A COAT ROD CLIP AS SHOWN




CLOSED FRONT & END BASES


IF THE SPACE BETWEEN THE BOTTOM OF THE LOCKERS
AND THE FLOOR IS TO BE CLOSED, FRONT AND END BASES
MUST BE ORDERED.

1) END BASES MUST BE ATTACHED BEFORE
THE LOCKER FOOT IS ATTACHED. END BASES
SLIDE UP OVER THE FRONT AND REAR LEGS
OF THE END LOCKERS.

2) A FRONT BASE IS INSTALLED BY SETTING IT
IN POSITION AND PUSHING IT BACK UNTIL THE
EMBOSSMENTS SNAP INTO THE LOCKER LEG.



LOCKER NUMBER PLATES



NO. 4
3/32" DIA. POP RIVET



POP RIVET GUN REQUIRED.
(NOT FURNISHED)

E-010120-2

**MISSING PARTS OR IN NEED
OF
ASSEMBLY ASSISTANCE?**

Contact us direct for fast friendly service (800) 433-8488


Int'l calls (630) 892-8941 | WEB: WWW.LYONWORKSPACE.COM | Fax (800) 367-6681

ACCESSORIES
FOR LYON
STEEL LOCKERS

LYON LYON WORKSPACE PRODUCTS
P.O. BOX 671
AURORA, IL 60507

6226-CA
SHEET 3 OF 6

PUNCHING PATTERNS



60" FLAT & SLOPING
UNIVERSAL SIDES & BACKS

72" FLAT & SLOPING
UNIVERSAL SIDES & BACKS

E-010120-2

**MISSING PARTS OR IN NEED
OF
ASSEMBLY ASSISTANCE?**

Contact us direct for fast friendly service (800) 433-8488

Int'l calls (630) 892-8941 | WEB: WWW.LYONWORKSPACE.COM | Fax (800) 367-6681

PUNCHING PATTERN
FOR LYON
STEEL LOCKERS

LYON LYON WORKSPACE PRODUCTS
P.O. BOX 671
AURORA, IL 60507

6226-CA
SHEET 4 OF 6

RECOMMENDED ANCHORING METHODS

(ANCHORS NOT FURNISHED BY LYON)

ANCHORS FOR MASONRY:



MIN. PULL-OUT
VALUE IN LBS.

- 3/16" SPRING WING TOGGLE BOLT-----200
- 9/64" DIA. HAMMER-IN DRIVE PINS
3/4" PENETRATION-----400
- 3/16" X 7/8" NAIL DRIVE ANCHORS-----500
- 1/4" SPRING WING TOGGLE BOLT-----650
- RAWPLUGS & #8 SHT. METAL SCREWS
1" PENETRATION-----1190
- EXPANSION SCREWS FOR #10-24 SCREWS
(MIN. LENGTH 5/8")-----1340
- 1/4" X 1 1/8" ONE PIECE ANCHOR BOLT-----1650
- 1/4" X 1 3/4" STUD ANCHORS-----1700

ANCHORS FOR WOOD:

MIN. PULL-OUT
VALUE IN LBS.

- .216" (#12) WOOD SCREWS
1" PENETRATION (2 REQ'D)-----120
- 1 1/2" PENETRATION-----180
- .242" (#14) WOOD SCREWS
1" PENETRATION (2 REQ'D)-----135
- 1 1/2" PENETRATION-----202
- 1/4" DIA. LAG BOLT
1" PENETRATION-----185
- 1 1/2" PENETRATION-----277
- 5/16" DIA. LAG BOLT
1" PENETRATION-----220
- 1 1/2" PENETRATION-----330



NOTE:

1) EXTREME END LOCKERS TO BE ANCHORED PLUS INTERMEDIATE LOCKERS ON 36" CENTERS MAX.

2) ALL BANKS OF LOCKERS TO BE TIED TOGETHER IN A MINIMUM OF 2 PLACES PER LOCKER. #10-24 NUTS & BOLTS CAN BE USED. RIVETS MAY NEED TO BE REMOVED FROM ATTACHING HOLES ON SET-UP LOCKERS.


POWER ACTUATED ANCHORS:

- 9/64" DIA. DRIVE PIN
3/4" PENETRATION-----315
- 5/32" DIA. DRIVE PIN
1" PENETRATION-----415


WARNING:

—FLOOR ANCHOR MUST HAVE A MINIMUM PULL-OUT VALUE OF 190 LBS.
—WALL ANCHOR MUST HAVE A MINIMUM PULL-OUT VALUE OF 150 LBS.


FREE STANDING SINGLE ROW LOCKERS WITH 6" LEGS




FREE STANDING SINGLE ROW LOCKERS



SINGLE ROW LOCKERS WITH 6" LEGS AGAINST A WALL



SINGLE ROW LOCKERS AGAINST A WALL



E-010120-2

MISSING PARTS OR IN NEED OF ASSEMBLY ASSISTANCE?

Contact us direct for fast friendly service (800) 433-8488

Int'l calls (630) 892-8941 | WEB: WWW.LYONWORKSPACE.COM | Fax (800) 367-6681

ANCHORING INSTRUCTIONS
FOR LYON
STEEL LOCKERS

LYON LYON WORKSPACE PRODUCTS
P.O. BOX 671
AURORA, IL 60507

6226-CA


SHEET 5 OF 6

FREE STANDING DOUBLE ROW LOCKERS WITH 6" LEGS

DOORS AND SHELVES NOT
SHOWN FOR CLARITY

LOCKER FOOT
SEE DETAIL A

WARNING:
ANCHOR MUST HAVE A MINIMUM
PULL-OUT VALUE OF 190 LBS.,
SPACED ON A MAXIMUM 36" CENTERS.




FREE STANDING DOUBLE ROW LOCKERS

DOORS AND SHELVES NOT
SHOWN FOR CLARITY


ANCHOR ANGLES
SEE DETAIL B

WARNING:
ANCHOR MUST HAVE A MINIMUM
PULL-OUT VALUE OF 190 LBS.,
SPACED ON A MAXIMUM 36" CENTERS.




SET-UP AND ALL-WELDED LOCKERS WITH & WITHOUT 6" LEGS (LEGS SHOWN)

DOORS AND SHELVES NOT
SHOWN FOR CLARITY



IN ADDITION TO THE INSTRUCTIONS FOR ANCHORING
LOCKERS: BOLT GROUPS SIDE BY SIDE IN 4 PLACES
WITH #10-24 x 1/2" SCREWS AND KEP NUTS.


DETAIL A LOCKER FOOT ASSEMBLY



ATTACH A LOCKER FOOT TO EACH FRONT LEG AS SHOWN. USE
A NO. 2 BOLT AND A PALNUT. IF END BASES ARE USED, THEY
MUST BE ATTACHED BEFORE THE LOCKER FOOT.

NOTE: DRAW NUT UP TIGHT AFTER LOCKERS ARE SET IN PLACE
AND LEVELED.

DETAIL B LOCKER ANCHOR ANGLE



1) CONNECT ANCHOR
ANGLE TO LOCKERS
WITH CONSTRUCTION
BOLTS AND NUTS.

2) DRILL ANCHOR
ANGLE AND SECURE
LOCKER THRU BOTTOM.
USE AN ANCHOR THAT
IS RECOMMENDED BY
LYON FOR MIN. PULL
OUT VALUE.
(SEE CHART)

E-010120-2

MISSING PARTS OR IN NEED OF ASSEMBLY ASSISTANCE?

Contact us direct for fast friendly service (800) 433-8488

Int'l calls (630) 892-8941 | WEB: WWW.LYONWORKSPACE.COM | Fax (800) 367-6681

ANCHORING INSTRUCTIONS
FOR LYON
STEEL LOCKERS

LYON LYON WORKSPACE PRODUCTS
P.O. BOX 671
50001 AURORA, IL 60507

6226-CA

SHEET 6 OF 6