



(2) 1/4-20 x 1/2"
T30 TORX PAN HEAD
TAPPING SCREW

SUPPLIED FASTENERS

INSTALLATION OPERATIONS

1. REFER TO OWNERS MANUAL FOR CABINET INSTALLATION AND ANCHORING.
2. DETERMINE THE LOCATION OF THE SHELF or SHELVES. INSTALL THE LEFT HAND AND RIGHT HAND SHELF SUPPORTS BY INSERTING THE REAR TANGS INTO THE RECTANGULAR SLOTS OF THE REAR FRAME MEMBER AND ATTACH FRONT OF SUPPORTS TO THE FRONT FRAME MEMBER WITH TAPPING SCREWS AS SHOWN. MAKE SURE THE SUPPORTS ARE LEVEL AND IN-LINE WITH EACH OTHER SIDE TO SIDE.
3. PLACE THE SHELF or SHELVES ON THE SUPPORTS

LYON P.O. Box 671
AURORA, IL 60507-0671
PHONE: 630-892-8941
FAX: 800-367-6681

NOTICE: THIS IS A CONFIDENTIAL DISCLOSURE LOANED BY LYON WORKSPACE FOR REFERENCE PURPOSES ONLY

| | | |
|------------------|----------------|-------------------|
| DATE 01-19-12 | DRAWN BY JR | CHECKED BY DWV |
|------------------|----------------|-------------------|

| | | |
|---|--|--|
| DESCRIPTION | | |
| INSTALLATION CABINET SHELF MDC | | |

| | | |
|------------|----------------------------------|----------|
| SHEET - | DRAWING NUMBER 5163-DA | REV 5 |
|------------|----------------------------------|----------|