



## INSTALLATION INSTRUCTIONS

- 1) DRAWERS-IN-SHELVING EXTERNAL LOCKBARS CAN ONLY BE MOUNTED TO THE T-POSTS AFTER ALL SHELVING, FRAMES AND DRAWERS HAVE BEEN INSTALLED.
- 2) LOCATE EXTERNAL LOCKBAR AS SHOWN ON THE LEFT SIDE OF THE DRAWERS. WITH A #27 ( $\varnothing 0.144$ ) DRILL BIT, USING THE HOLES ON THE HINGE OF THE EXTERNAL LOCKBAR AS A GUIDE, DRILL HOLES THROUGH THE T-POST.
- 3) SECURE THE EXTERNAL LOCKBAR TO THE T-POST USING THE SUPPLIED THREAD CUTTING SCREWS.

**LYON** P.O. Box 671  
AURORA, IL 60507-0671  
PHONE: 630-852-8943  
FAX: 800-367-6681

NOTICE: THIS IS A CONFIDENTIAL DISCLOSURE LOANED BY LYON WORKSPACE FOR REFERENCE PURPOSES ONLY

DATE 01-31-12	DRAWN BY JR	CHECKED BY DWV
------------------	----------------	-------------------

DESCRIPTION

INSTALLATION  
DIS ELB  
MDC

SHEET -	DRAWING NUMBER <b>SS1444</b>	REV 1
------------	---------------------------------	----------