ATTACHMENT OF STEEL TOP CHANNELS 240860 STEEL CHANNEL (UNEQUAL LEG) Steel Attachment Channels for Modular Drawer Cabinets have one leg longer than the other, known as "unequal leg" Steel Channels. They are assembled to the Steel Top in lieu of the "equal leg" Steel Channels that are supplied with the Steel Top Kit. These "equal leg" Steel Channels will not be used. Assemble "unequal leg" Steel Attachment Channels to the Steel Top using the hardware supplied with the Steel Top Kit. Attach each 1/4-20 x 3/4 -MACHINE SCREW Channel using three (3) 1/4-20 x 3/4 Flat Head Machine Screws, three (3) External Tooth Lockwashers and three (3) 1/4-20 Hex Nuts as shown. LOCKWASHER -1/4-20 HEX NUT -STEEL TOP P.O. Box 671 AURORA, IL 60507-0671 PHONE: 630-892-8941 SCREW FAX: 800-367-6681 NOTICE: THIS IS A CONFIDENTIAL DISCLOSURE LOANED BY LYON WORKSPACE FOR REFERENCE PURPOSES ONLY CHECKED BY DRAWN BY 01-28-12 DESCRIPTION WASHER INSTALLATION CHANNEL 28D STEEL TOP ATTACHMENT CHNL MDC DRAWING NUMBER SS1330 1