



LOCKER SHALL BE ANCHORED THROUGH THE BOTTOM AND THROUGH THE BACK OR TOP IN AN APPROVED WORKMANLIKE MANNER BY THE LOCKER ERECTOR. THE GENERAL CONTRACTOR IS TO INSTALL WOOD GROUNDS IN THE BASE.

WOOD STRIPS AT THE BACK, IF USED, ARE TO BE INSTALLED BY THE GENERAL CONTRACTOR TO ALLOW FACE OF LOCKER TO BE FLUSH WITH FINISHED WALL SURFACE.





SECTION B-B

- 7. ATTACH TOP FLANGE OF TOP TRIM TO TOP CROSS MEMBER OF EACH ROW WITH $\#10 \times 1/2$ " HEX SELF DRILLING SCREW AS SHOWN IN SECTION "B-B".
- 8. REMOVE TOP, CENTER AND BOTTOM BOLTS FROM DOOR FRAMES AT ENDS OF EACH ROW. ATTACH SIDE TRIM PIECES WITH THREE $\#10 \times 1/2$ " SHEET METAL SCREWS FROM INSIDE OF LOCKER THROUGH SIDE TRIM PIECE. SEE SECTION "A-A".
- 9. HOLD TOP AND SIDE TRIM PIECES TIGHTLY AGAINST FACE OF RECESS. TIGHTEN SHEET METAL SCREWS TO HOLD IN PLACE.

- 1. ALIGN AND PLUMB LOCKERS, IN RECESS, SO THE DOOR FRAMES ARE FLUSH WITH FINISHED WALL SURFACE.
- 2. LOCKER GROUPS ARE BOLTED TOGETHER THROUGH DOOR FRAMES ONLY.
- 3. CAREFULLY LEVEL THE ROW OF LOCKERS BY PLACING SHIMS UNDER THE DOOR FRAMES AT THE LOW POINTS.
- 4. WHEN ANCHORING LOCKERS, BE SURE TO MAINTAIN ALIGNMENT IN RECESS. EACH END LOCKER SHOULD BE ANCHORED. (REFER TO ANCHORING INSTRUCTIONS FOR RECOMMENDED ANCHORING METHODS)
- 5. TOP TRIM PIECES ARE FURNISHED IN 60" LENGTHS. ERECTOR TO CUT REQUIRED LENGTHS.

